



Installation Instructions For Inlet Protection Domes

Step One

Place Inlet Protection Dome over inlet. Ensure that dome completely covers inlet opening.



Step Two

Place Filter over frame.



Step Three

Fill pockets of filter with gravel (typically #57 stone) or soil.

Note: Ensure the pockets and frame have good contact with the earth or surface around the inlet. This contact is what prevents undermining.



Step Four

Optional: Cut an inspection window/emergency overflow /removal hole that matches the round hole at the top of each dome.



Actual Photos of installed S400B-DOT After an 8" Rain Event in 45 minutes Hwy and Inlet was protected!